

# Metal & Cable Corp., Inc.

9337 RAVENNA ROAD, UNIT C P.O. BOX 117

TWINSBURG, OH 44087

PHONE (330) 425-8455

FAX (330) 963-7246

**\*\*\*FAILURE TO READ AND FOLLOW INSTRUCTIONS  
MAY LEAD TO RISK OF INJURY OR DEATH\*\*\***



## FALL HAZARD

**FAILURE TO FOLLOW THIS WARNING  
MAY RESULT IN SERIOUS INJURY OR  
DEATH.**

Use OSHA approved fall protection  
equipment when installing mount.

Mount NOT man-rated. Do not lean on  
mount, hang on mount, or use mount for  
support.



## MAGNET HAZARD

**FAILURE TO FOLLOW THIS CAUTION  
MAY RESULT IN INJURY OR PROPERTY  
DAMAGE.**

Mount contains magnetic components.

- **PINCH HAZARD.** Interaction with magnets on mount may create a pinch hazard.
- **PROPERTY HAZARD.** Electronic objects such as cell phones, hearing aids, and beepers may be damaged.



## DETACHMENT HAZARD

**FAILURE TO FOLLOW THIS WARNING  
MAY RESULT IN SERIOUS INJURY OR  
DEATH.**

Failure to follow installation  
instructions, including application of  
correct torque values, may create a  
mount detachment hazard. Mount must  
remain tethered to tower at all times.



## CUT HAZARD

**FAILURE TO FOLLOW THIS CAUTION  
MAY RESULT IN INJURY.**

Metal components of mount may have  
sharp edges. Use care and wear OSHA  
approved protective clothing, work  
gloves, and safety glasses when handling  
and installing mount.



MAGNET HAZARD

**FAILURE TO FOLLOW THIS WARNING  
MAY RESULT IN SERIOUS INJURY OR  
DEATH.**

Mount contains magnetic components. Wearers of cardiac pacemakers, implantable cardioverter defibrillators (ICDs) or other metallic, magnetic, or mechanical implants, devices or objects should not come into contact with mount.

## Metal & Cable Corp., Inc.

9337 RAVENNA ROAD, UNIT C      P.O. BOX 117  
TWINSBURG, OH 44087  
PHONE (330) 425-8455      FAX (330) 963-7246

### Installation instructions for Magnemount MMSA-38, or Magnet Assemblies

**Do not remove the Poly pads on the bottom of the magnets. They are an integral part of the system!!!**

Tools needed: None

- 1) **Do not place on top of a weld.**
- 2) Prior to the installation of the cable holders – **DO NOT REMOVE THE ATTACHED BUBBLE WRAP UNTIL THEY ARE ABOUT TO BE INSTALLED.**
- 3) Please, wipe the surface on the tank beneath the magnet to maximize the holding power of the magnets.
- 4) Spacing of the MMSA-38 mounts should be 2 feet when mounted vertically, or 3 feet when mounted horizontally.
- 5) When ready to install, remove the bubble wrap and place on the tank.
- 6) There are no adjustments to be made.

## **Removal**

- 1) Pull the adapter to the side to release the magnet.
- 2) Cover the magnet to keep it free of debris.

Any questions at any time, call David Klein at 330-963-7909 (direct)