

Metal & Cable Corp., Inc.

9337 RAVENNA ROAD, UNIT C P.O. BOX 117

TWINSBURG, OH 44087

PHONE (330) 425-8455

FAX (330) 963-7246

*****FAILURE TO READ AND FOLLOW INSTRUCTIONS
MAY LEAD TO RISK OF INJURY OR DEATH*****



FALL HAZARD

**FAILURE TO FOLLOW THIS
WARNING MAY RESULT IN SERIOUS
INJURY OR DEATH.**

Use OSHA approved fall protection
equipment when installing mount.

Mount NOT man-rated. Do not lean on
mount, hang on mount, or use mount for
support.



MAGNET HAZARD

**FAILURE TO FOLLOW THIS
CAUTION MAY RESULT IN INJURY
OR PROPERTY DAMAGE.**

Mount contains magnetic components.

- **PINCH HAZARD.** Interaction with magnets on mount may create a pinch hazard.
- **PROPERTY HAZARD.** Electronic objects such as cell phones, hearing aids, and beepers may be damaged.



DETACHMENT HAZARD

**FAILURE TO FOLLOW THIS
WARNING MAY RESULT IN SERIOUS
INJURY OR DEATH.**

Failure to follow installation instructions,
including application of correct torque values,
may create a mount detachment hazard.
Mount must remain tethered to tower at all
times.



CUT HAZARD

**FAILURE TO FOLLOW THIS
CAUTION MAY RESULT IN INJURY.**

Metal components of mount may have sharp
edges. Use care and wear OSHA approved
protective clothing, work gloves, and safety
glasses when handling and installing mount.



MAGNET HAZARD

FAILURE TO FOLLOW THIS WARNING MAY RESULT IN SERIOUS INJURY OR DEATH.

Mount contains magnetic components. Wearers of cardiac pacemakers, implantable cardioverter defibrillators (ICDs) or other metallic, magnetic, or mechanical implants, devices or objects should not come into contact with mount.

Metal & Cable Corp., Inc.

9337 RAVENNA ROAD, UNIT C P.O. BOX 117
TWINSBURG, OH 44087
PHONE (330) 425-8455 FAX (330) 963-7246

Instructions for cable tray and cable

6-magnet Magnemount Model CT1000-30-U-6 Tools needed:
1/2" open ended wrench, 1/2" deep socket, torque wrench

Do not remove the Poly pads on the bottom of the magnets.
They are an integral part of the system!!!

General layout requirements

- 1) Cable tray covers (if being used) to be a maximum of 4" high.
- 2) Cable tray should preferably be 12" wide, or a maximum of 24" wide.
- 3) The cable tray and cover should be made of aluminum.
- 4) The Magnemount Cable Tray holders must be mounted to the tank before the cable tray is attached.

- 5) At least 2 Magnemount Cable Tray holders must be mounted directly next to each other at the ends (bottom and top), or the bottom of the cable tray should be anchored to the ground.
- 6) **Do not place any of the magnets on the Magnemounts across a weld.**

Installation instructions

- 1) Do not remove the bubble wrap until the Magnemounts are ready to be installed.
- 2) The Magnemounts should be spaced according to project engineering specifications if closer than those recommended on our web site. Metal & Cable recommends spacing of 2 feet, or closer, for side of tank applications and 3 feet, or closer, for top of tank placement applications.
- 3) Remove all dirt from the installation area - preferably with a damp cloth. This will greatly aid the holding power of the mounts.

Keep fingers clear of the bottom of the magnets when installing.

- 4) Remove the bubble wrap from the magnet bases and place the cable tray mounts on the tower **BEFORE ATTACHING THE CABLE TRAY.**
- 5) If needed, alignment can be adjusted by tapping the channel on the ends with a rubber mallet.
- 6) Loosen all double nuts (6 sets) until full contact is made with the tank.
- 7) When all magnets are contacting the tank, tighten the bottom nuts **ONLY UNTIL IT CONTACTS THE WASHER INSIDE THE UNISTRUT.** Tightening any more reduces the holding capacity of the mount.

- 8) Bring the top nut down to contact the bottom nut. Hold the bottom nut with a 1/2" open ended wrench and tighten the top nut using **10 pound-feet** of torque.
- 9) The strut should now be firmly mounted in all directions.
- 10) Attached the cable tray and cables to the Magnemounts.

Removal

Lift one end of the Mount and all of the magnets will release.

Any questions at any time, call David Klein at 330-963-7909