

# Metal & Cable Corp., Inc.

9337 RAVENNA ROAD, UNIT C      P.O. BOX 117  
TWINSBURG, OH 44087  
PHONE (330) 425-8455      FAX (330) 963-7246

## Installation instructions for Magnemount MMSA-38 or Magnet Assemblies

Tools needed: None

- 1) **Do not place on top of a weld.**
- 2) Prior to the installation of the cable holders – DO NOT REMOVE THE ATTACHED BUBBLE WRAP UNTIL THEY ARE ABOUT TO BE INSTALLED.
- 3) Please, wipe the surface on the tank beneath the magnet to maximize the holding power of the magnets.
- 4) Spacing of the MMSA-38 mounts should be 3 feet when mounted vertically, or 4 feet when mounted horizontally.
- 5) When ready to install, remove the bubble wrap and place on the tank.
- 6) There are no adjustments to be made.

## Removal

- 1) Pull the adapter to the side to release the magnet.
- 2) Cover the magnet to keep it free of debris.

Any questions at any time, call David Klein at 330-963-7909 (direct)