

Metal & Cable Corp., Inc.

9337 RAVENNA ROAD, UNIT C P.O. BOX 117
TWINSBURG, OH 44087
PHONE (330) 425-8455 FAX (330) 963-7246
Internet Address: www.metal-cable.com

Installation instructions for all 5-plate Magnemount MASS models

Tools needed

3/4" deep socket, 3/4" open ended wrench, 1/2" open ended wrench, 1/2" deep socket, **torque wrench (important!)**, 5/16" wrench

Location note - In order to achieve maximum holding strength;

Model MASS should have no full outside rows of side saddle magnets on tank welds.

Installing the center section (the plate with the short mast)

- 1) When removing all mount sections from the shipping container (while on the ground) **DO NOT REMOVE THE ATTACHED INSULATING BASE.** This will keep the magnets free of debris and the mount from attaching to unwanted objects.
- 2) After the mount sections are on top of the tower, please remove all "dirt". Just wiping the surface will improve the holding power.

****Lift by the plates only - keep hands and feet clear of the magnets****

- 3) *****Caution –**Without the insulator attached, hold the plate by the sides only because the magnets will take the plate out of your hands with no warning when it gets close to the tower.*******
- 4) Stand the plate up on its edge – orient the base direction - remove the insulating base - then set the plate down on the tower.
- 5) Totally loosen the double hex nuts on all 24 magnets at least 1/4" above the plate. This will allow the magnets to be independently seated.
- 6) **FINGER-TIGHTEN** each bottom hex nut. Hold the bottom nut in place with the 1/2" open ended wrench, **and with the torque wrench**, tighten the top nut using 10#-ft of torque. Do not use power tools!!!
- 7) The center section is now installed.

Installing the side saddles

- 1) Set the sidesaddles on each side of the center section, with the connecting straps facing the center section.
- 2) Remove the 4 sets of double nuts from each side of the center section. Place the connecting straps over the 4 bolts and replace the lock-nut and nut just below the top of the bolts. **Move the plate as close to the center plate as possible.** Cut the plastic wrap holding the insulating base. Lift the back end of the plate, remove the insulating base, and while holding the plate ONLY, set the plate down on the tower.
- 3) Totally loosen the double hex nuts on all 24 magnets at least ¼” above the plate. This will allow the magnets to be independently seated.
- 4) FINGER-TIGHTEN each bottom hex nut. Hold the bottom nut in place with the ½” open ended wrench, **and with the torque wrench**, tighten the top nut using 10#-ft of torque. Do not use power tools!!!
- 5) Tighten the double nuts on the straps each the same way as in 4). Do not tighten the bars down to the center plate surface – that will lift the side plate.

Installing the elbow and top mast

Note: When the upper mast is attached to the base by the elbow, until the upper mast is raised, the upper mast must be supported above the top of the short mast to prevent possible damage to the support arms.

- 1) Remove the 4 sets of 3/8” bolts/lockwashers from the shanks of the elbow.
- 2) Place one shank end of the elbow into the lower mast. Insert the upper mast into the other shank end. Raise the mast and level it. Replace the spacers/lockwashers/bolts into the **bottom** mast through opposite slots in the mast that align with the threads on the shank. Tighten these bolts to 30 foot-pounds of torque. Next, tighten the ½” internal tooth lockwashers and double nuts to 50 foot-pounds of torque. Rotate the upper mast so that the eyebolts are in line with the plates.
- 3) Replace the spacers/lockwashers/bolts into the **upper** mast through opposite slots in the mast that align with the threads on the shank. Tighten these bolts to 30 foot-pounds of torque.

Installing the guy wires

- 1) Attach the guy wires to the turnbuckles. Hold the guy wires with the enclosed wire clips – 3 per cable.
- 2) Tighten the turnbuckles by HAND ONLY!! The aim is to only remove the slack in the cable. Over tightening the cables will reduce the holding capacity of the Magnemount.
- 3) For safety – tether the mount to the tower.

Removal

- 1) Insert the enclosed 1.50" bar at the indicated area under the plate (or at any of the 4 corners) and lift the edge of the plate.
- 2) Cover the magnets with plastic, cardboard, foam board, or other barrier to keep ferrous materials from sticking to the magnets.

If you have any question at any time, please call David Klein at 330-963-7909.