

Metal & Cable Corp., Inc.

9337 RAVENNA ROAD, UNIT C P.O. BOX 117

TWINSBURG, OH 44087

PHONE (330) 425-8455

FAX (330) 963-7246

*****FAILURE TO READ AND FOLLOW INSTRUCTIONS
MAY LEAD TO RISK OF INJURY OR DEATH*****



FALL HAZARD

**FAILURE TO FOLLOW THIS WARNING
MAY RESULT IN SERIOUS INJURY OR
DEATH.**

Use OSHA approved fall protection equipment when installing mount.

Mount NOT man-rated. Do not lean on mount, hang on mount, or use mount for support.



MAGNET HAZARD

**FAILURE TO FOLLOW THIS CAUTION
MAY RESULT IN INJURY OR
PROPERTY DAMAGE.**

Mount contains magnetic components.

- **PINCH HAZARD.** Interaction with magnets on mount may create a pinch hazard.
- **PROPERTY HAZARD.** Electronic objects such as cell phones, hearing aids, and beepers may be damaged.



DETACHMENT HAZARD

**FAILURE TO FOLLOW THIS WARNING
MAY RESULT IN SERIOUS INJURY OR
DEATH.**

Failure to follow installation instructions, including application of correct torque values, may create a mount detachment hazard. Mount must remain tethered to tower at all times.



CUT HAZARD

**FAILURE TO FOLLOW THIS CAUTION
MAY RESULT IN INJURY.**

Metal components of mount may have sharp edges. Use care and wear OSHA approved protective clothing, work gloves, and safety glasses when handling and installing mount.



MAGNET HAZARD

**FAILURE TO FOLLOW THIS WARNING
MAY RESULT IN SERIOUS INJURY OR
DEATH.**

Mount contains magnetic components.
Wearers of cardiac pacemakers, implantable
cardioverter defibrillators (ICDs) or other
metallic, magnetic, or mechanical implants,
devices or objects should not come into
contact with mount.

Metal & Cable Corp., Inc.

9337 RAVENNA ROAD, UNIT C P.O. BOX 117
TWINSBURG, OH 44087
PHONE (330) 425-8455 FAX (330) 963-7246

Installation instructions for
Magnemount CT1000-24-U-2 Cable Support Tools –
1/2” deep socket, 1/2” open ended wrench,
and a torque wrench

**USE NO POWER TOOLS Do not remove the Poly pads on the
bottom of the magnets. They are an integral part of the system!!!**

- 1) **Do not place magnets on top of a weld.**
- 2) **DO NOT REMOVE THE BUBBLE WRAP UNTIL THEY ARE READY TO BE INSTALLED.**
- 3) Supports should be spaced according to local and national building codes or project engineering specifications if closer than those recommended on our web site. Metal & Cable recommends spacing of 2 feet for vertical applications and 3 feet for horizontal (or dome placement) applications.
- 4) Remove all “dirt and droppings” from the installation area – preferably with a damp cloth only. Please, for better magnet holding power, wipe the area clean.

Keep fingers clear of the bottom of the magnets when installing.

- 5) Remove bubble wrap from the magnet bases and place the cable supports on the tower.

- 6) Back off the double nuts until the magnets fully contact the tower. Fingertighten the bottom hex nuts until they contact the washer inside the Unistrut. While holding the bottom nut in place with the open ended wrench, tighten the top hex nut with **10#-ft (no more than that amount) of torque.**
- 7) Alignment on the tank can be adjusted by tapping the channel with a rubber mallet.

Removal

Lift one end of the support and the magnet will release.

Any questions at any time, call David Klein at 330-963-7909 (direct)